



- 1) "A" and "B" start, reset Interlock Box #1.
- 2) "A" and "B" reset Interlock Box #2. "A" continues to hold while "B" sweeps the shielding cart spur.
- 3) "A" holds while "B" sweeps the tunnel and reset Interlock Boxes #3 and #4.
- 4) "B" joins "A" and they sweep the hall.
- 5) "A" holds while "B" resets Interlock Box #5 and checks the Target tube area then the RAW skid area.
- 6) "B" joins "A" and exit and reset Interlock Box #6.

Reviewed AD/RSO	Date
<i>Michael A. Gerardi</i>	4-1-09
Approved AD/OPS Dept. Head	Date
<i>[Signature]</i>	4-2-09